

Christmas Timer

How to set current time:

Hold down clock button until day of week flashes, tap set until hour flashes, then plus/minus to get to current hour.

Tap set until minute flashes, plus/minus to current minute flashes.

Tap clock symbol.

Program/change on and off:

Tap mode button until it reads auto off.

Hold down program button until days of the week/on time is displayed.

To change days of the week, tap plus/minus until Monday through Sunday flashes.

Tap set, then hours will display.

Then plus/minus until the hour on time you want is displayed.

Then tap set button, then plus/minus until minute you want on is displayed.

Tap set button once, then plus/minus until Monday through Sunday flashes again.

Tap set again until hour is flashing, plus/minus until the hour you want it off is displayed.

Tap set again, the minutes is flashing, plus/minus until the minute want off is there.

Tap clock button.

If none of the above works, reset the timer and start over. Follow reset instructions below:

Reset Button, at bottom on front of timer, use a toothpick, to push the reset button inside.

Timer will remove all previous settings so you can start from beginning.